

## BBQ LIGHTING PROCEDURE

1. Press and turn black knob to "Pilot" position
2. Press and hold black knob for 1 minute to allow gas to reach the pilot burner
3. Whilst still pressing the black knob, push the red lighter switch button (you'll hear it click/spark)
4. Continue to hold the black knob for a further 1 minute to ensure gas is flowing to burners
5. Once you can see the burners are lit, press and turn the black knob to the "Open" position
6. Adjust the burners accordingly with the square red knobs (they will ignite by themselves)
7. When finished turn all red burner knobs to off and the black knob to the "off" position
8. Leave the BBQ and dining area clean, tidy and free from rubbish (bin and wipes provided)